

Suction filter

Type S 8 to S 455

RE 51491 Edition: 2023-02 Replaces: 2021-04



Features

Suction filters are used in hydraulic systems for separating solid particulate from hydraulic and lubrication fluids. The suction filters are designed to be screwed into the suction line on pumps or inside reservoirs.

- Cleanable wire mesh filter media. Information on filter material configuration is available in RE 51548.
- Filtration of hydraulic fluids and lubricants
- ► Filtration of industrial fluids
- Direct installation into suction lines
- Direct wear protection of pumps
- Bypass valve and return flow protection possible

Contents

Features	1
Ordering code for suction filter	2
Symbols	3
Function, section	3
Technical data	4
Dimensions	5
Assembly, commissioning, maintenance	6
Tightening torques	6
Environment and recycling	6
Guidelines and standards	7
Intended use	8
Improper use	8

- Nominal size 8 ... 455 ►
- Connection up to G 3 ►
- ► Filter rating from 10 µm nominal

Ordering code Suction filter

01	02	03	 04	 05	 06	-07	80	09
			S00		00	-		

Design

01 Suction filter	S
-------------------	---

Frame size

02	S	8
		16
		28
		45
		75
		115
		175 280 455
		280
		455

Nominal filter rating in µm

03	Stainless steel wire mesh, cleanable	G10
		G25
		G40
		G60
		G100
		G130
		G200
		G500
		G800

Element design

	04	Standard adhesive T = 100 °C	S00
--	----	------------------------------	-----

Solenoid / bypass valve / maintenance indicator


05	without solenoid, without bypass valve, without maintenance indicator	000
	without solenoid, with bypass valve 0.3 bar, without maintenance indicator, not configurable with check valve	010
Port		
06	Standard	00
Seal		
07	without	0
Mate	rial	
08	Standard	0
Supp	lementary information	
09	without	0
	Check valve 0.02 bar, only possible with frame size 75, 115, 175, 280, 455; not configurable with bypass valve	v

More detailed information on Hengst filter material configuration is available in RE 51548.


Order example: S45 G100-S00-000-00000

Symbols

Filter symbol with bypass




Filter symbol with reverse flow check valve



Function, section

Suction filters are used in hydraulic systems for separating solid particulate from hydraulic and lubrication fluids. They are intended for the direct attachment to suction lines

The suction filter consists of a combination of star-like pleated filter media (4) which is wrapped around a perforated support tube (3). The suction filter is sealed in a longitudinal direction, using a 2-component adhesive. The support tube and filter element mesh-pack are glued to the upper part (1) and the end caps (2).



Technical data

(for applications outside the stated values, please consult us!)

Weight	Neight		8	16	28	45	75	115
		kg [lbs]	0.1	0.12	0.14	0.24	0.3	0.45
			[0.22]	[0.27]	[0.31]	[0.53]	[0.66]	[0.99]
		NG	-	280	455			
		kg [lbs]		1.46	1.6			
			[1.28]	[3.22]	[3.5]			
Operating tem	nperature range	°C [℉]] –20 +100 [-4 +212]					
Storage condi	tions	°C [℉]	-40 +65	[40+149]; max. rela	tive air humi	dity 65%	
Material	 Upper part 		Polyamide	with frame s	size 16 to 17	75		
			Aluminum with frame size 8, 280 and 455					
	 Support tube 		Galvanized steel					
	► Base		Galvanized	steel				

hydraulic		
Flow direction		from the outside to the inside
Maximum differential pressure	bar [psi]	1 [14.5]

Compatibility with permitted hydraulic fluids


Hydraulic fluid		Classification	Standards	
Mineral oil		HLP	DIN 51524	
Bio-degradable	- insoluble in water	HETG		
		HEES	VDMA 24568	
	- soluble in water	HEPG	VDMA 24568	
Flame-resistant	- water-free	HFDU, HFDR	VDMA 24317	


Important information on hydraulic fluids!


► For further information and data on the use of other hydraulic fluids, please refer to data sheet 90220 or contact us!

Dimensions

(dimensions in mm)







Туре	Dimensions (mm)									
	ØA	В	B1: For version with check valve	С	ØD: For version with check valve	SW				
S 8	40	45		G 3/8		24				
S 16	57	60		G 1/2		36				
S 28	57	90		G 3/4		36				
S 45	77	95	155	G1	55	55				
S 75	77	130	190	G 1 1/4	55	55				
S 115	109	135	189	G 1 1/2	75	75				
S 175	109	180	234	G 2	75	75				
S 280	150	169	254	G 2 1/2	105	105				
S 455	150	249	334	G 3	105	105				

Assembly, commissioning & maintenance

Assembly

Install the suction filter directly to the suction line of the pump. Vertical installation preferred.

Commissioning

Commission the system.

Maintenance

- If the suction filter is contaminated (recommendation max. 0.3 bar underpressure (absolute)), it should be replaced or cleaned
- Switch off the system
- ► Screw off the suction filter
- ▶ Replace or clean the suction filter
- Suction filters made of wire mesh can be cleaned. The cleaning process requirements depend on the type of contamination and the differential pressure obtained before the suction filter service interval For detailed cleaning instructions, refer to data sheet RE 51548
- Install on the new or cleaned suction filter
 The torque specifications ("Tightening torques" section) are to be considered
- Commission the system

Tightening torques

(dimensions in mm [inch])

Series suction filter S	8	16	28	45	75	115	175	280	455
Suction filter	25 Nm ± 10 Nm								

Environment and recycling

The used suction filter has to be disposed of according to the country-specific legal regulations for environmental protection.

Notice:

 If the recommended differential pressure is disregarded, the disproportionally increasing differential pressure may damage the suction filter (collapse). Warranty expires in the event that the delivered item is changed by the ordering party or third parties or improperly mounted, installed, maintained, repaired, used or exposed to environmental conditions that do not comply with the installation conditions.

Guidelines and standards

Product validation

Hengst filters are tested and quality-monitored according to different ISO test standards:

Compatibility with hydraulic fluid ISO 2943:1998-11

The development, manufacture and assembly of Hengst industrial filters and Hengst filter elements is carried out within the framework of a certified quality management system in accordance with ISO 9001:2015.

Use in potentially explosive atmospheres according to directive 2014/34/EU (ATEX):

The suction filters are not equipment or components in the sense of directive 2014/34/EU and are not provided with the CE mark.

It has been proven with the ignition risk analysis that these suction filters do not have own ignition sources according to DIN EN ISO 80079-36.

The suction filters can be used for the following potentially explosive atmospheres:

	Zone suitability	
Gas	1	2
Dust	21	22

WARNING!		
 For use of the suction filters in potentially explosive atmospheres, ATEX suitability of the complete filter assembly is an imperative requirement. Conductivity of the medium: at least 300 pS/m During suction filter exchange, the packaging material 	 is to be removed from the suction filter outside the potentially explosive atmosphere. Maintenance to be conducted only by specialists, as per the instruction by the machine end-user according to DIRECTIVE 1999/92/EC Appendix II, section 1.1 	

Intended use

The suction filters serve as components as per the EC Machinery Directive 2006/42/EC in hydraulic machinery for the separation of dirt particles.

The suction filters are to be used under the following boundary conditions and limits:

- ▶ only in hydraulic systems with fluids of group 2, according to Pressure Equipment Directive 2014/68/EU
- > only according to the application and environmental conditions in the chapter "Technical data"
- only with hydraulic fluids and the intended seals according to the section "Compatibility with hydraulic fluids"
- ► Use in potentially explosive atmospheres according to the chapter "Guidelines and standards"
- Compliance with application and environmental conditions according to the technical data
- Compliance with the specified performance limits
- > The suction filters are intended exclusively for professional use and not for private use

Improper use

Any use deviating from the intended use is deemed as improper and thus not permissible. Improper use of the suction filters includes:

- Incorrect storage
- Incorrect transport
- Lack of cleanliness during storage and assembly
- Incorrect installation
- ► Use of inappropriate/non-permissible hydraulic fluids
- Operation outside the approved temperature range
- ► Installation and operation in impermissible device group and category

Hengst Filtration GmbH does not assume any liability for damage caused by improper use. The user assumes all risks involved with improper use.

Hengst Filtration GmbH Hardtwaldstr. 43 68775 Ketsch, Germany Phone +49 (0) 62 02 / 6 03-0 hydraulicfilter@hengst.de www.hengst.com © This document, as well as the data, specifications and other information set forth in it, are the exclusive property of Hengst Filtration GmbH. It may not be reproduced or given to third parties without consent of Hengst Filtration GmbH. The data specified above only serve to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information. The information given does not release the user from the obligation of own judgment and verification. It must be remembered that our products are subject to a natural process of wear and aging.